

Panel van spare wheel detail	24
Cruise Control	24

PANEL VAN SPARE WHEEL DETAIL

Please refer to the Fiat / Peugeot handbook.

CRUISE CONTROL

The driver of the vehicle should always remain seated and in control of the vehicle when the cruise control has been engaged. Never leave the driving seat for any reason when the vehicle is underway.